



HI-LINE
DESIGN

DF GOBLIN RIGID CHASE TAILLIGHT MOUNTS

KIT CONTENTS

- (2) RIGID CHASE TAILLIGHT MOUNT

ADDITIONAL MATERIALS REQUIRED

- (2) RED RIGID CHASE LIGHT (RIGID PN: 90133) OR EQUIVALENT
- (4) #10-32 BOLT
- (8) #10 WASHER
- (4) #10-32 NYLOCK NUT

MOUNTING INSTRUCTIONS

1. PAINT OR POWDER COAT THE RAW MOUNTING BRACKETS
2. ATTACH THE RIGID CHASE LIGHTS TO THE MOUNTING BRACKETS USING THE 6-32X3/8" ALLEN SCREWS INCLUDED WITH THE LIGHTS
3. USING EXCESS HARDWARE FROM YOUR GOBLIN KIT, OR SOURCED LOCALLY, MOUNT THE BRACKETS TO THE DF GOBLIN CHASSIS
4. CONNECT WIRES PER THE DIAGRAM BELOW WITH WATERPROOF CONNECTORS

WIRING DIAGRAM (NO RESISTORS NEEDED!)

<u>RIGID CHASE LIGHT</u>	<u>DF GOBLIN HARNESS</u>
RED (PARKING)	BROWN (PARKING)
WHITE (BRAKE/TURN SIGNAL)	YELLOW/DARK GREEN (BRAKE/TURN SIGNAL)
BLUE (REVERSE)	LIGHT GREEN (REVERSE)
BLACK (GROUND)	BLACK (GROUND)

YELLOW & GREEN ARE UNUSED

VERIFY PER YOUR WIRE THINNING